

PRODUCT DESCRIPTION

Nerolac Impressions IDEAZ is a Special Effect Designer series range that creates a variety of designs on interior walls in matte finish.

PERFORMANCE FEATURES & BENEFITS



RECOMMENDED USAGE

Nerolac Impressions IDEAZ can be applied on the interior surfaces such as smooth plaster, brickwork, cement rendering, concrete, hardboard, building boards, etc.

SURFACE PREPARATION

- 1 Ensure the surface is clean, dry, free from all defective or poorly adhering material, din, grease, wax etc. Remove all loose or poorly adhering materials by rubbing down, using suitable abrasive paper and thereafter wipe off
- Apply a coat of suitable Nerolac Interior Primer Sealer followed by Nerolac Wall Putty to level the dams and make the surface uniform.
- 3 Apply again a coat of suitable Nerolac Interior Primer Sealer.
- Then apply two to three coats of Nerolac Beauty Gold Acrylic Plastic Emulsion.

RECOMMENDED SYSTEM FOR APPLICATION

For New Masonry Surfaces

- 1 Interior Primer** (1 Coat) Dry in 4 6 hrs
- 2 Acrylic Wall Putty## (1 Coat) Dry in 6 8 hrs
- 3 Interior Primer** (1 Coat) Dry in 4 6 hrs
- 4. Finish coat (1 Coat) Nerolac Impressions Ideaz (as per design required)

Sand the surface with emery paper and wipe clean before application of subsequent coat.

**Nerolac Interior Prime (waterthinnable).

##Nerolac Acrylic Wall Putty.

#Minimum 4-6 hrs for Water Thinnable Primer.

TECHNICAL DATA COVERAGE** On smooth and non-al







DRYING TIMESurface Dry: 45 - 30 Minutes





RECOATING

Min. 4 - 6 hrs. (@27°± 2°C & RH 60 ± 5%)







GLOSS LEVEL Soft Sheen DRY FILM THICKNESS (IN MICRONS)/COAT 100-125






voc


< 125 gms/ltr.



"*Actual coverage may vary depending on Method, Condition of Application, Type of Tools, Surface Porosity & Shade. Use of Felt Roller may reduce coverage upto 50%.

PRECAUTIONS







3. Keep away from children.

- 4. In case of eye/skin contact wash with plenty of water.
- 5. Inhalation/Injection can be dangerous. In either case, move to fresh air & consult medical practitioners.
- 6. Do not apply when the ambient temperature might drop to levels below 10°C within 4 hrs of application.
- 7. New plaster should be allowed to cure for minimum of 12 weeks.
- 8. The container must be tightly closed when not in use. Stir well before use.
- 9. Use safety equipment like rubber or polythene gloves, safety goggles/glasses & face masks.

SAFETY FEATURES:

For removing stains, sponge clean with a mild soap solution and wipe clean. Ensure a drying time of 1 week before cleaning.

SAFETY FEATURES:







COLOR: No Shade.

